


FIG. 1






FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7





FIG. 8







FIG. 10



<u>APPLIANCE MODE</u>		
WARNING MESSAGES:		
<u>PRIORITY</u>	<u>UNIT</u>	<u>MESSAGE</u>
1	FREEZER	TOO HOT, TEMP = 34°F
2	FURNACE	PRESSURE TOO HIGH CHECK AIR FILTER
3	WATER HEATER	TEMP TOO HIGH TEMP = 140°F
4	REFRIG.	TIME TO VACUUM DUST FROM CONDENSER COILS

FIG. 11




FIG. 12

